

www.fittertraining.com 16" x 18"									
NO:	PIPE BRACH HOLE MARKING CUT BACK								
CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°	CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°
R 1	2	3	5	8	C 1	29	29	29	29
R 2	7	11	16	24	C 2	59	59	59	59
R 3	11	19	26	39	C 3	88	88	88	88
R 4	15	25	35	53	C 4	116	116	116	116
R 5	19	31	43	65	C 5	143	143	143	143
R 6	23	36	49	74	C 6	169	169	169	169
R 7	25	39	53	80	C 7	191	191	191	191
R 8	28	40	54	81	C 8	209	209	209	209
R 9	29	40	52	76	C 9	221	221	221	221
R 10	30	37	46	67	C 10	226	226	226	226
R 11	30	32	39	54	C 11	221	221	221	221
R 12	29	28	31	41	C 12	209	209	209	209
R 13	28	24	25	30	C 13	191	191	191	191
R 14	25	20	20	23	C 14	169	169	169	169
R 15	23	17	16	17	C 15	143	143	143	143
R 16	19	14	12	13	C 16	116	116	116	116
R 17	15	10	9	9	C 17	88	88	88	88
R 18	11	7	6	6	C 18	59	59	59	59
R 19	7	4	4	3	C 19	29	29	29	29
R 20	2	1	1	1	C 20	0	0	0	0

www.fittertraining.com 16" x 20"									
NO:	PIPE BRACH HOLE MARKING CUT BACK								
CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°	CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°
R 1	2	3	5	7	C 1	29	29	29	29
R 2	7	11	15	23	C 2	59	59	59	59
R 3	11	18	25	38	C 3	88	88	88	88
R 4	15	24	33	51	C 4	115	115	115	115
R 5	19	30	41	62	C 5	141	141	141	141
R 6	23	34	46	70	C 6	165	165	165	165
R 7	25	37	50	75	C 7	186	186	186	186
R 8	28	39	51	76	C 8	202	202	202	202
R 9	29	38	49	72	C 9	212	212	212	212
R 10	30	36	45	65	C 10	216	216	216	216
R 11	30	33	40	55	C 11	212	212	212	212
R 12	29	29	34	45	C 12	202	202	202	202
R 13	28	25	28	36	C 13	186	186	186	186
R 14	25	22	23	28	C 14	165	165	165	165
R 15	23	18	18	22	C 15	141	141	141	141
R 16	19	15	14	16	C 16	115	115	115	115
R 17	15	11	11	12	C 17	88	88	88	88
R 18	11	8	7	8	C 18	59	59	59	59
R 19	7	5	4	4	C 19	29	29	29	29
R 20	2	1	1	1	C 20	0	0	0	0