

www.fittertraining.com 16" x 22"									
NO:	PIPE BRACH HOLE MARKING CUT BACK								
CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°	CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°
R 1	2	3	5	7	C 1	29	29	29	29
R 2	7	11	14	22	C 2	59	59	59	59
R 3	11	17	24	36	C 3	87	87	87	87
R 4	15	24	32	49	C 4	115	115	115	115
R 5	19	29	39	59	C 5	140	140	140	140
R 6	23	33	44	67	C 6	163	163	163	163
R 7	25	36	48	71	C 7	182	182	182	182
R 8	28	38	49	72	C 8	197	197	197	197
R 9	29	37	48	70	C 9	207	207	207	207
R 10	30	36	45	64	C 10	210	210	210	210
R 11	30	33	40	56	C 11	207	207	207	207
R 12	29	30	35	47	C 12	197	197	197	197
R 13	28	26	30	39	C 13	182	182	182	182
R 14	25	23	25	31	C 14	163	163	163	163
R 15	23	19	20	25	C 15	140	140	140	140
R 16	19	16	16	19	C 16	115	115	115	115
R 17	15	12	12	14	C 17	87	87	87	87
R 18	11	9	8	9	C 18	59	59	59	59
R 19	7	5	5	5	C 19	29	29	29	29
R 20	2	2	1	2	C 20	0	0	0	0

www.fittertraining.com 16" x 24"									
NO:	PIPE BRACH HOLE MARKING CUT BACK								
CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°	CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°
R 1	2	3	4	7	C 1	29	29	29	29
R 2	7	10	14	21	C 2	59	59	59	59
R 3	11	17	23	35	C 3	87	87	87	87
R 4	15	23	31	47	C 4	114	114	114	114
R 5	19	28	38	57	C 5	139	139	139	139
R 6	23	32	43	65	C 6	162	162	162	162
R 7	25	35	46	69	C 7	180	180	180	180
R 8	28	37	48	70	C 8	194	194	194	194
R 9	29	37	47	68	C 9	203	203	203	203
R 10	30	36	44	63	C 10	206	206	206	206
R 11	30	33	40	57	C 11	203	203	203	203
R 12	29	30	36	49	C 12	194	194	194	194
R 13	28	27	31	41	C 13	180	180	180	180
R 14	25	24	26	34	C 14	162	162	162	162
R 15	23	20	21	27	C 15	139	139	139	139
R 16	19	16	17	21	C 16	114	114	114	114
R 17	15	13	13	16	C 17	87	87	87	87
R 18	11	9	9	11	C 18	59	59	59	59
R 19	7	5	5	6	C 19	29	29	29	29
R 20	2	2	2	2	C 20	0	0	0	0