

www.fittertraining.com 16" x 26"									
NO:	PIPE BRACH HOLE MARKING CUT BACK								
CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°	CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°
R 1	2	3	4	7	C 1	29	29	29	29
R 2	7	10	14	21	C 2	59	59	59	59
R 3	11	17	22	34	C 3	87	87	87	87
R 4	15	23	30	46	C 4	114	114	114	114
R 5	19	28	37	55	C 5	139	139	139	139
R 6	23	32	42	63	C 6	160	160	160	160
R 7	25	35	45	67	C 7	178	178	178	178
R 8	28	36	47	69	C 8	192	192	192	192
R 9	29	36	46	67	C 9	201	201	201	201
R 10	30	35	44	63	C 10	204	204	204	204
R 11	30	34	41	57	C 11	201	201	201	201
R 12	29	31	36	50	C 12	192	192	192	192
R 13	28	28	32	43	C 13	178	178	178	178
R 14	25	24	27	36	C 14	160	160	160	160
R 15	23	21	22	29	C 15	139	139	139	139
R 16	19	17	18	23	C 16	114	114	114	114
R 17	15	13	14	17	C 17	87	87	87	87
R 18	11	9	10	12	C 18	59	59	59	59
R 19	7	5	5	7	C 19	29	29	29	29
R 20	2	2	2	2	C 20	0	0	0	0

www.fittertraining.com 16" x 28"									
NO:	PIPE BRACH HOLE MARKING BACK								
CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°	CENTER LINE	TEE BRANCH 90°	LAT-ERAL 60°	LAT-ERAL 45°	LAT-ERAL 30°
R 1	2	3	4	7	C 1	29	29	29	29
R 2	7	10	13	20	C 2	59	59	59	59
R 3	11	16	22	33	C 3	87	87	87	87
R 4	15	22	30	45	C 4	114	114	114	114
R 5	19	27	36	54	C 5	138	138	138	138
R 6	23	31	41	61	C 6	160	160	160	160
R 7	25	34	44	66	C 7	177	177	177	177
R 8	28	36	46	67	C 8	191	191	191	191
R 9	29	36	46	66	C 9	199	199	199	199
R 10	30	35	44	63	C 10	202	202	202	202
R 11	30	34	41	57	C 11	199	199	199	199
R 12	29	31	37	51	C 12	191	191	191	191
R 13	28	28	32	44	C 13	177	177	177	177
R 14	25	25	28	37	C 14	160	160	160	160
R 15	23	21	23	30	C 15	138	138	138	138
R 16	19	17	19	24	C 16	114	114	114	114
R 17	15	13	14	18	C 17	87	87	87	87
R 18	11	10	10	12	C 18	59	59	59	59
R 19	7	6	6	7	C 19	29	29	29	29
R 20	2	2	2	2	C 20	0	0	0	0